

5. Once the filter cartridges have been inserted into the correct housing cores **reinstall the threaded caps** by first making sure that the housing O-Rings are in place and have had the surface coated lightly with the FDA Silicone provided. The silicone allows the surface of the threaded cap to glide smoothly on the O-Ring surface for equal compression and to avoid kinking or dislodging of the O-Ring which will result in leaking. The threaded filter caps should be tightened by hand firmly in the opposite direction of the arrows shown on the caps. The "A" cap will tighten by turning it to the left, counter clockwise. The "B" cap will tighten by turning it to the right, clockwise, as shown in **figure B**.

6. With the filter still lying flat on its side, turn on the cold water and activate the faucet diverter. Allow the water to run and check for leaks around the threaded caps. If any leaks are noticed try tightening the caps slightly more or repeat step 5. If no leaks are noticed, return the filter to the upright position and allow the water to run 2-3 minutes until all cloudiness and discoloration have gone. With a piece of tape or label of some kind note the date of this replacement on the bottom or back side of the filter housing. Be sure to replace the filter cartridges every 6 months for optimum performance.

www.aquasana.com





Countertop/Under-Counter
Replacement Cartridges

US Item #4025 / CDN #904025

Replacement Cartridge Instructions

IMPORTANT!

Read these instructions completely before installing the enclosed Replacement Cartridges.



This product is intended for use on municipally treated cold water supplies only and is not designed for use with water of unsafe or unknown bacteriological quality. For specific contaminant reduction claims see the Performance Data Sheet on our website at www.aquasana.com

Steps:

1. With the filter system laying flat on your countertop and hoses still connected, as shown in **Figure A**, **remove the threaded filter caps** by turning in the direction of the arrows.

2. **Remove both filter cartridges** and O-Rings. These cartridges may be disposed of with your trash, as it poses no environmental hazards.

3. Install new O-Rings as shown in **Figure A**. **Rub FDA Silicone around the exposed surface of the O-Ring** to ensure a proper seal.

4. As shown in **Figure B**; **install the new filter cartridges** with the "A" cartridge being placed in the "A" housing core with the O-Ring end first. Install the "B" cartridge into the "B" housing core with the O-Ring end last.

www.aquasana.com